

Switching

3Com

Choosing which firmware to boot

verifying current versions:

> show version

setting next-active to the backup (before update) one:

> boot system backup

setting next-active to the active (most recent) one:

> boot system active

Reset to defaults:

<https://www.vmadmin.co.uk/networking/81-hp-3com/358-reset-3com-switch-to-factory-defaults-forgot-password>

Cisco

ACLs

Adding ACL example

```
360 permit tcp any 10.3.4.102 0.0.0.0 eq 8000
```

Removing last ACL

```
no 360
```

Global features

Filtering output

"COMMAND | i" or "COMMAND | include" will filter command output

example:

"switch1#show running-config | i trunk"

"switch1#show running-config | include trunk"

Revision #1

Created 2026-03-04 09:51:44 UTC by Diogo Gonalo Loureno

Updated 2026-03-04 09:51:44 UTC by Diogo Gonalo Loureno